



## Quick Reference Guide


**Machine Homing:** Drive the X and Y axis to the lower left of the table or 6" from the stop switches. Under



**Home** click **All**.

**Correct Program Zeroing:** Drive the machine to the desired location to start. Select **Set Start**. Ensure the Coordinates are all **0.0000**.

**Machine wont move:** Ensure the power button in HALO is on.



**Torch Diving:** Ensure correct settings in **SheetCam**, Amperage, Material Thickness and Hypertherm machine is set to correct amperage. Check consumables for correct amperage and wear. Ensure voltage in **HALO** is within +/- 5 of targeted voltage.

**Torch Raising:** Remove consumables and inspect. Clean torch's shield of debris or replace.

**Failed to Detect Arc Error or No Fire:** Check the Hypertherm for error codes. Error code meanings can be found in the Hypertherm and BOSS Table manuals. Check ground clamp for corrosion and locking end for tightness at the Hypertherm. Replace consumables.

**Torch Fails to Cut Material:** Check for proper settings in **SheetCam**, proper amperage on power unit. Check consumable tip for wear and correct amperage. Refer to cut chart that selected consumables are correct size or selection.

**Scribe Wont Vibrate:** Remove hose from the top of the scribe. Pour 1 drop of tool oil into the scribe and install the hose. With the scribe on tap the side of the scribe with a wrench. This will clear any debris in the scribes airway.

**Powering On:** Power on the Belkin power strip, Power on the controller, Power on the pc.

**Powering Off:**Power off the pc, Power off the controller, Power off the power strip.

### Homing

Homing sets the dimensions for the tables driving parameters **ONLY**. Once homed the program will zero the machines coordinates. **This is not used to zero material or program coordinates!**

### Zeroing

Zeroing sets the start point for a cut that is determined on the material location of your choosing. Zero the machine by selecting **Set Start**.

## **Powermax Error Codes**

<b>Warning/Fault codes</b> (refer to operator manual)	
0-12	Low input gas pressure: warning
0-13	AC input unstable: warning
0-19	Power board hardware protection
0-20	Low gas pressure
0-21	Gas flow lost while cutting
0-22	No gas input
0-30	Torch consumables stuck
0-32	End of consumable life
0-40	Over temperature
0-50	Retaining cap off
0-51	Start/trigger signal on at power up
0-52	Torch not connected
0-60	AC input voltage error
0-61	AC input unstable: shutdown
0-98	Internal communication failure
0-99	System hardware fault – service required

**BOSS Tables Technical Support**

Ron 563-217-0657

Dakota 563-217-9610